


JAKES LIFT KITS
G-22 SPINDLE KIT PART
PART# 6255
U.S. PAT. 7185901

PARTS LIST



ITEM	QUANTITY
A. PASSENGER SIDE SPINDLE	1
B. DRIVER SIDE SPINDLE	1
C. REAR GOALPOST	1
D. REAR SWAY BAR	1
E. WARNING LABEL (NOT PICTURED)	1

JAKES LIFT KITS

G-22 SPINDLE KIT PART # 6255


FRONT INSTALLATION

1. Jack up the front end of the cart and place it on jack stands. You will be installing larger wheels and tires so raise the cart high enough to accommodate for the additional height.
2. Remove the wheels and tires.
3. Remove the steering arms from the spindles.
4. Remove the spindles and the stock bushings from the spindles. Clean and lubricate these bolts and bushings for the reinstallation of the spindles.
5. Install the stock bushings to JAKES spindles. Install Jakes spindles. NOTE: Spindles are stamped 6255-D (Item B) and 6255-P (Item A).
6. Reattach the steering arms to the same location to the new spindles.
7. Securely tighten all bolts.
8. Install JAKES recommended 22 x 11 x 10 wheels and tires with a 3 x 5" offset for maximum performance and stability. NOTE: Your stock wheels and tires will NOT work!
9. Take the cart off of the jack stands and lower the cart.
10. Drive the cart forward 10-20 feet and check the toe-in. (Proper toe-in should be approximately 1/8".)


REAR INSTALLATION

1. Remove the rear body assembly if necessary. (Not all bodies will require removing.)
2. Remove the rear sway bar at the frame end. (Driver's side)
3. Raise the rear of the cart and place the frame on jack stands. (Make sure you raise cart high enough for larger tires.)
4. Remove the rear tires.
5. Remove the rear shocks.
6. Install JAKES rear goalpost (Item C) to the top stock shock mount location as shown using the provided nuts and bolts. NOTE: **The "J" in the center of the rear goalpost should be facing the rear of the cart.**
7. Install the shocks to the goalpost using the stock hardware. (You may have to oversize the lower shock mount holes enough to eliminate shock bind.)
8. Install JAKES new triangular shaped sway bar bracket (Item D) to the driver's side of the cart and reconnect the sway bar. (Some carts may require enlarging the left rear bag-well hole down through the frame with a 3/8" drill bit to secure the sway bar.)
9. Securely tighten all bolts.
10. Install your new wheels and tires and lower cart to the floor. NOTE: Your stock wheels and tires will NOT work!
11. Install the rear body assembly if needed.
12. Make sure you have enough length for the choke cable, ground wires, vacuum lines, fuel lines and the electrical wire. (The choke in some cases, may need lowered in the body 1 - 2" and remounted for adequate length.)
13. Included is a warning label (Item E) which is to be placed on the steering column or another visible area and is to be read by all operators.
14. Double check all of the bolts for tightness.

Rear Goalpost/Shock Riser Installation



Rear Sway Bar Mount Installation



NOTE: Some models may need the inner fenders heated, reformed or cut for tire clearance.